




For Future Use

Wet location electrical outlets should be GFI



- Kitchen:**
- GFI for countertop outlets
  - Dishwasher wire to left of sink
  - Undercounter lights
  - Electric Oven
  - Gas Cooktop (requires plug to start)

Track Lights on dimmers

All recessed ceiling lights need dimmers

All Fans have 2 switches  
-Light  
-Fan

-To spotlight

① Alarm Panel

⊕ Alarm Contact  
CLG

